


Model No.DC18RD TWO PORT MULTI FAST CHARGER



Model No.DC18RD TWO PORT MULTI FAST CHARGER

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/Old	Note1	Note2
001	804Y51-3	INDICATION LABEL		1			
002	804Y52-1	MAKITA LOGO LABEL		1			
003	455546-5	TERMINAL COVER		2			
004	231474-6	COMPRESSION SPRING 4		4			
005	142845-1	CHARGER CASE COMPLETE		1			
D10		INC. 6,7					
006	455402-9	LENS B		1			
007	455401-1	LENS A		1			
008	804Y47-4	CHARGING CONDITION LABEL		1			
009	266278-7	TAPPING SCREW FLANGE BT3X10		2			
010	632E11-3	TERMINAL UNIT		2			
011	638499-5	SCIROCCO FAN		2	*		
011-1	638499-5	SCIROCCO FAN	O	2			
012	266764-8	TAPPING SCREW 3X8		4			
013	233194-8	COMPRESSION SPRING 4		2			
014	455399-2	TERMINAL BASE		2			
015	620120-0	CHARGING CIRCUIT		2			
D10		INC. 16,17					
016	652800-0	FUSE		2			
017	647306-1	VARISTOR		2			
018	667708-5	POWER SUPPLY CORD		1			
019	620324-4	FILTER CIRCUIT		1			
020	620326-0	USB CIRCUIT		1	*		
020-1	620412-7	USB CIRCUIT	<	1	*		
021	455398-4	CHARGER CASE COVER		1			
022	455403-7	USB COVER		1	*		
022-1	412817-3	COVER	<	1			
023	286255-3	CAP 13		4			
024	266426-8	TAPPING SCREW 4X20		6			
025	850E35-9	DC18RD NAME PLATE		1			
F01	196933-6	DC18RD 2PORT FAST CHARGER SET		1			
A01	450128-8	BATTERY COVER		3			
A02	197280-8	BATTERY BL1850B SET		3	*		
A02-1	197280-8	BATTERY BL1850B SET	O	3			
F01	198458-6	DC18RD 2PORT FAST CHARGER SET		1			
A02	197265-4	BATTERY BL1840B SET		2	*		
A02-1	197265-4	BATTERY BL1840B SET	O	2			
F01	199481-4	DC18RD 2PORT FAST CHARGER SET		1			
F01	199482-2	DC18RD 2PORT FAST CHARGER SET		1			
F01	199483-0	DC18RD 2PORT FAST CHARGER SET		1			
A02	197422-4	BATTERY BL1860B SET		2	*		
A02-1	197422-4	BATTERY BL1860B SET	O	2			
F01	199484-8	DC18RD 2PORT FAST CHARGER SET		1			

F01	199485-6	DC18RD 2PORT FAST CHARGER S ET		1			
-----	----------	-----------------------------------	--	---	--	--	--

Please state Parts No. when your order.

Print Date 05/24/2024